

# « Quick Start Guide »

# X5 STEREO BLUETOOTH HEADSET

## Quick Start Guide

### « Inside the package »

- One X5 Stereo Bluetooth Headset
- One Voice Enabled Audio Streamer
- One Detachable Microphone
- One set of Foam Speaker Covers
- One 3.5mm Audio lead
- One 3.5mm Y-Cable Audio Lead
- Two USB Cables
- One AC Charger
- One X5 User Guide



### « Pairing the X5 to the Audio Streamer »


1. Mount the batteries. Insert the small end of a USB cable into the USB port on the X5 and plug the large end into a computer USB port. Do the same for the Audio Streamer (or use the AC charger). Charge the X5 and Audio Streamer for 2 hours before use.
2. On the Headset, press & hold ON/OFF and Vol Up buttons for about 5 seconds. Led flashes blue to red.
3. On the Audio Streamer, press & hold the ON/OFF button for about 5 seconds. Led will flash blue to red.
4. At this point the two devices will automatically pair and connect with each other.
5. To connect with your computer, insert the single black plug of the Y-Cable into the jack input of the Audio Streamer. On the Y end, insert the red plug into the microphone input of your computer and insert the black plug into the Stereo output of your computer.
6. At this stage, the connection between Headset and Audio Streamer is in stereo mode. Open an audio program on your computer and play a song. To increase volume, Short Click the Vol Up button. To decrease, Short Click the Vol Down button. Also you may need to adjust volume levels of the computer Soundcard.
7. To use with a VOIP program, e.g. Skype, MSN Messenger...etc, insert the detachable USB Microphone into the USB port of the Headset. Next, switch from Stereo to Voice mode by clicking the ON/OFF button on the X5 once.
8. Open the program and use its interface to control the call. To switch back to Stereo music mode after ending a Voice call, click MFB button of the X5 Headset once.
9. If you have been listening to music via stereo mode, then on an incoming VOIP call, you will hear the bell tone intermingled with the sound of music. To switch to Voice mode, first stop or pause the music on the computer and then click ON/OFF button of the Headset once to enter into Voice mode.
10. When using different audio sources, e.g. Mp3 player, iPod, TV...etc, plug one end of the stereo 3.5mm cable into the Audio Streamer, and the other end into your audio device. Music plays through the Headset.

### « Function / Button matrix »

X5 Functions	Button	Time	Conditions / Status
Turn Headset ON	On/OFF	3 sec	Headset Off
Pairing Headset	ON/OFF & Vol Up	3 sec	Headset Off
Pick Up	MFB	Click	To Telephone
Hang Up (profile dependent)	MFB or ON/OFF	Click	During a call
Last Call Redial / Voice Dialing (depending on phone)	MFB	3 sec	Standby
Volume Up	Vol Up	Click	During Communication
Volume Down	Vol Down	Click	During Communication

Remote Control Functions (AVRCP compatible devices only)			
Play	MFB	Click	While Stopped or Paused
Pause	MFB	Click	While Playing
Stop	ON/OFF	Click	While Playing
Next Song	Vol Up	1 sec	While Playing
Previous Song	Vol Down	1 sec	While Playing

Streamer Functions	Button	Time	Conditions / Status
Turn Audio Streamer ON	ON/OFF	3 sec	Streamer Off
Turn Audio Streamer OFF	ON/OFF	3 sec	Streamer On
Pairing Audio Streamer	ON/OFF	5 sec	Streamer Off
Reconnect with Headset	ON/OFF	3 sec	Streamer Off
Switch from Stereo to Voice	ON/OFF	Click	While Playing
Switch from Voice to Stereo	MFB	Click	While in voice mode



« Pairing X5 to a Phone or PDA »

Note: This is an example only and may differ from phone to phone

1. Ensure the X5 is charged.
2. On the Headset, press & hold the On/OFF and Vol Up buttons for about 5 seconds.
3. Led flashes blue to red
4. Reboot the mobile phone to refresh its memory. Turn Bluetooth ON in your phone.
5. Perform a device discovery to search for the X5. (Some devices require you to pair once for High Quality Audio and again for Handsfree, e.g. HP 6515. Other phones require pairing only once but will enable both services e.g. Samsung D600)
6. When devices are displayed, select the X5 Stereo. Enter Passkey "1234".
7. Set the X5 Stereo as a trusted/authorised device, if an option in your phone.
8. Finish and exit.
9. If required, select the X5 Stereo in the Bluetooth devices list and press Connect.
10. Refer to your phones User Manual for any additional steps



« Reconnecting the X5 »

When the X5 has been disconnected (by switching off or going out of range) you will need to reconnect

1. To reconnect with the Streamer simply turn both the X5 Headset and Audio Streamer On and they will connect automatically.
2. To connect back to your phone go to its Bluetooth Menu, select the X5 Stereo in the Paired devices list and press connect



« LED indicator chart »

Headset LED	Status
LED OFF	Bluetooth Link Established
Blue LED flashes every sec	Standby (Connectable/Pairing) mode
Red and Blue LED Flash	Pairing Mode

Headset Status	LED Indicator
Power On	Blue LED flashes rapidly and then flashes slow periodically
Power OFF	Red LED flashes rapidly and then OFF
Incoming call	Blue LED flashes rapidly
Low battery Level	Red LED flashes every second
Charging state	Red LED ON
Charging Complete	Red LED OFF with periodic Blue LED flash

Audio Streamer LED	Status
Blue LED ON with periodic flash	Bluetooth Link Established
Blue LED flashes rapidly and then change to alternating Blue and Red flashes	Pairing Mode
Blue LED flashes rapidly and then flashes slowly	Power ON
Red LED flashes Red rapidly & then OFF	Power OFF
Red LED flashes every second	Low Battery Level
Red LED	Charging State
Red LED Off with periodic Blue LED flash	Charging Complete
Constant Red LED	Charging While Connected To USB

